

Fuse	Rating	Location	Feeds
A	450A	Battery Post Fusible Links	Starter Motor 450A Diesel
B	100A	Battery Post Fusible Links	Continuous feed to Fuse box
C	100A	Battery Post Fusible Links	IGNITION POWER SUPPLY
D	100A	Battery Post Fusible Links	IGNITION and Accessory POWER SUPPLY
E	80A	Battery Post Fusible Links	IGNITION POWER SUPPLY
N	100A	Battery Post Fusible Links	Glow Plug control Unit
A	150A	Battery Post Fusible Links	Starter Motor 150A Petrol
B	100A	Battery Post Fusible Links	Continuous feed to Fuse box
C	100A	Battery Post Fusible Links	IGNITION POWER SUPPLY
D	100A	Battery Post Fusible Links	IGNITION and Accessory POWER SUPPLY
E	80A	Battery Post Fusible Links	IGNITION POWER SUPPLY
F	60A	Engine Bay Fuse box	EPS Control unit (Power Steering)
G	30A	Engine Bay Fuse box	Headlamp Waher
H	30A	Engine Bay Fuse box	ABS Control unit and Pump
I	50A	Engine Bay Fuse box	ABS Control unit and Pump
J	50A	Engine Bay Fuse box	BCM for Power Windows
K	40A	Engine Bay Fuse box	Engine Room Distribution
L	40A	Engine Bay Fuse box	Ignition Switch
M	40A	Engine Bay Fuse box	Continuous feed to Fuse box
1	10A	Internal lower dash fuse panel	Ignition On supply to BCM
2	10A	Internal lower dash fuse panel	Air Bag System
3	10A	Internal lower dash fuse panel	Meters
4	10A	Internal lower dash fuse panel	Washer Motor
5		Internal lower dash fuse panel	
6		Internal lower dash fuse panel	
7		Internal lower dash fuse panel	
8	10A	Internal lower dash fuse panel	Data link Connector, Light and rain sensor, Intell Key buzzer
9	10A	Internal lower dash fuse panel	Combination Meter Supply
10	10A	Internal lower dash fuse panel	Map lights, Luggage room lights, step lamp, Continuous supply to BCM
11	10A	Internal lower dash fuse panel	Stop Lamp switch and Stop lamp switch relay

12	10A	Internal lower dash fuse panel	4WD Control Unit
13	15A	Internal lower dash fuse panel	Driving Lamp Relay
14	10A	Internal lower dash fuse panel	Ignition Key switch solenoid
15	10A	Internal lower dash fuse panel	Blower
16	15A	Internal lower dash fuse panel	Blower
17		Internal lower dash fuse panel	
18	15A	Internal lower dash fuse panel	Cigarette Lighter Socket
19	15A	Internal lower dash fuse panel	Front power socket / luggage room socket
20	10A	Internal lower dash fuse panel	Audio Unit, Tel Adaptor, BCM, Door Mirrors
31	20A	Engine Bay Fuse box	Heated seat relay
32		Engine Bay Fuse box	Turbo Cooling pump
33	10A	Engine Bay Fuse box	Theft warning siren
34	10A	Engine Bay Fuse box	Horn and Alternator
35	15A	Engine Bay Fuse box	Continuous supply to AUDIO unit and Tel adaptor
36		Engine Bay Fuse box	
37		Engine Bay Fuse box	
38	10A	Engine Bay Fuse box	Tranmission Control Module
43	10A	Underside of IPDM	Headlamp High RHS, Front Combination lamps RHS, Driving lights relay
44	10A	Underside of IPDM	Headlamp High LHS, Front Combination lamps LHS
45	10A	Underside of IPDM	TAIL LAMPS License plate, Back door opener, Switch illuminations,
46	10A	Underside of IPDM	rear combination Lamps, PARKING LAMPS
47			
48	30A	Underside of IPDM	
49	15A	Underside of IPDM	Headlamp Low LHS, Front Combo lamps Low
50	15A	Underside of IPDM	Headlamp Low RHS, Front Combo lamps Low, Aiming Motor
51	10A	Underside of IPDM	
52		Underside of IPDM	
53			
54			
55	15A	Underside of IPDM	
56	15A	Underside of IPDM	
57	15A	Underside of IPDM	

58	10A	Underside of IPDM	
59	10A	Underside of IPDM	ABS System
60	10A	Underside of IPDM	Back Up Lamp (Reversing Lights)
61	15A	Underside of IPDM	Throttle Control Motor
62	20A	Underside of IPDM	Ign Coils, ECM Relay,Cam pos sensor, MAFS,Turbo boost valve,FUEL PUMP
63	15A	Underside of IPDM	
64	15A	Underside of IPDM	
65	15A	Underside of IPDM	Fog Lamps RHS AND LHS